
INSTALLATION INSTRUCTIONS

MS 100 S



MS and MS...S

- For round air guidance (preferably folded spiral-seams ducts) according to DIN EN 1506, for shutting off or continuously controlling air flows in room air-related systems. Particularly well suited to tight spaces. Use of the MAICO MSR 100 160 accessory simplifies mounting considerably. One unit comprises shutter drive and air shutter.
- Other common features:
 - Current reduction in standby or holding mode
 - Shutter blade and servomotor require no maintenance
 - Can be used in systems up to 1,000Pa
 - IP 54 degree of protection
 - Self-adjusting after installation
- MS supply voltage 230V: Shutter with Open Closed position. Opening angle can be adjusted using a mechanical stop such that the shutter doesn't close completely. For example, basic and demand-based ventilation can thereby be easily provided.
- MS...S supply voltage 24V AC/DC: Shutter with permanent shutter position. Shutter controlled using 2-10V signal.



- 1 Air direction
- 2 Mounting
- 3 Cable duct
- 4 Shutter blade
- 5 Shutter blade direction of rotation