INSTALLATION INSTRUCTIONS

WRG 35-SE



Features

- Simultaneous ventilation and air extraction possible.
- If necessary, pure supply air or exhaust air operation can also be set.
- With 2 integrated G4 filters, F7 filter optional.
- No disturbing parts inside, just a flat designer cover.
- Housing and wall sleeve made entirely from noise-insulating EPP, which makes them particularly well suited to living rooms and bedrooms.
- Cold air does not flow in when the unit it switched off thanks to electric external shutters.
- Optional accessories make it suited to various wall thicknesses.

The components of the decentralised WRG 35 air unit with heat recovery:

Needed:

- Set for final WRG 35-SE assembly
 - Complete fan unit with heat recovery.
 - Including internal cover and two G4 filters.
- Set for WRG 35-SR shell
 - Scope of delivery: wall sleeve (3 parts), 2 plaster protective covers, reinforced cross with stop for spirit level and stainless steel external cover with drilling template.
- RLS 4 room air control (AP = Surface-mounted, UP = Recessed-mounted)
 - The WRG 35-SE is activated by the RLS 4 room air control.

Optional:

- WRG 35-VH extension sleeve
 - Scope of delivery: extension sleeve, 2 separating bridges and condensation hose.
- WRG 35-AR compensating frame
- WRG 35-G4 replacement filter
- WRG 35-F7 replacement filter

