## **INSTALLATION INSTRUCTIONS**

## WS 600



## **Operator unit for WS 600**

- The WS 600 room air system is remotely controlled using a separate operator unit. The ventilation levels or day/week programs etc. can therefore be set.
- The operator unit is connected to the central device using a shielded 5-core cable. It has a maximum length of 100 m. The operator unit can then be fitted virtually anywhere in a detached single-family unit house.
- Dimensions of operator unit:

■ Width: 150 mm■ Height: 80 mm■ Depth: 32 mm

