WIRING DIAGRAM

DZQ 50/4 B Ex t



