WIRING DIAGRAM

DZR 60/6 B Ex e



