
WIRING DIAGRAM

ER-AP 100





S1 switch On / Off