


WIRING DIAGRAM

ERR 12/1 EC



Adjustable speed




WIRING DIAGRAM

ERR 12/1 EC



Speed adjustable via potentiometer



WIRING DIAGRAM

ERR 12/1 EC



Maximum speed

