

# WIRING DIAGRAM

## ERR 25/1 EC



### Adjustable speed



# WIRING DIAGRAM

## ERR 25/1 EC



Speed adjustable via potentiometer



# WIRING DIAGRAM

## ERR 25/1 EC



### Maximum speed

