


## WIRING DIAGRAM

# ER 60 G



### ER 60 G



S1 = Base load (low speed)  
S2 = Full load (high speed)

---