


## WIRING DIAGRAM

EZD30-6A

EZD...D for ventilation




Right-hand rotation: EZD...D with air drawn across the motor

---

## WIRING DIAGRAM


EZD30-6A

EZD...D for air extraction




Right-hand rotation: EZD...D with air blown across the motor

EZD...D with VE shutter, RKP and MS 8, MS 8 P servomotor



\* Limit switch only for MS 8 P

EZD... with VE shutter, RKP and ST, STU, STS speed controller



\* Limit switch only for MS 8 P