
WIRING DIAGRAM

MS 160



MS 100 / 125 / 150 / 160 - open / closed shutter position



MS 160



MS 100 / 125 / 150 / 160 - shutter position with intermediate settings

