
## PP 60 KA



## Connection for PushPull 60 K ventilation units to RLS PP-K room air control



P - PushPull Fan F - Fan KI - Shutter St - Connector NT - Mains adapter SV - Power Supply